



- 1. WinAIR mounting bracket
- 2. U-shaped brackets
- 3. Washers
- 4. Bolts

Installation

- Install WinAIR pressure gauge onto mounting bracket by using small screws supplied in the WinAIR packaging
- Use U-shaped brackets along with washers and bolts to hold mounting bracket into place