





- 1. WinAIR Flush mounting bracket
- 2. Plastic tube
- 3. Screws
- 4. Anchors

Installation

- Install WinAIR pressure gauge onto the Flush Mount bracket by using the small and long screws, along with the bracket supplied in the WinAIR packaging
- Use Screws and Anchors to wall mount the assembly